

SEE NOTE 3


CUSTOMER SUPPLY FROM LOCAL ISOLATOR

RUN SEE LINK ON WEBSITE FOR VARIOUS WAYS CONTROL CAN BE USED

AIR FLOW SWITCH (FITTED) 604X
OVERHEAT CUT OUT (FITTED) OHC5

ROOM SENSOR (OPTIONAL)
RS1
DUCT SENSOR (FITTED)

- NOTES :
- 1) THE AAH/6 IS STAR POINT BUT MUST HAVE A NEUTRAL SUPPLY FOR CONTROL
 - 2) CABLE SIZE WILL DEPEND ON THE POWER OF THE HEATER
 - 3) OPTIONAL FAN SUPPLY (MAX 650W @ 230V) TEMPERATURE CONTROLLED AND CONTINUOUS RUN WITH FAN RUN ON SEE LINK FOR CONTROL OF 3~ FAN
 - 4) SEE WEBSITE UNDER DOWNLOADS FOR HEATING & VENTILATION OPTION

 ALL AROUND HEATING
 PRODUCTS LTD
 WRING DRAWING
 FOR AAH/6
 SSR CONTROL
 400V 3 PHASE